


# Airtherm Ex Air Heater System





## Airtherm Ex Air Heater System

Pos.	Description	Art. No.	Art. No.
1	Controller 1-channel	140-112-31003HT	
	Controller 2-channel	140-112-31003HT2	
2	Mains cable	140-112-31012	
3	Heating cartridge	140-112-31004B	140-32-32032-x-x
4	Isolation sleeve	140-112-31005	
5	Jacket pipe	140-112-31008	
6	Airtherm hose		
7	Distributor housing		
8	Control cable		
9	Connector NG8		
10	Plug for controller		

### References to the order of spare parts

You can order the necessary spare parts with the help of the spare parts drawing on page 16.

The Airtherm Ex hose and the control cable are manufactured in different lengths and combinations.

**Because of the Ex permission the Airtherm Ex hose and the Airtherm EX control cable can only be delivered completely with the distributor housing!**

Part number: 140-32-32032-x-x

Without indication of the last quota figures the standard version will be delivered:

Airtherm Ex hose length 10 m  
 Airtherm Ex control cable length 10 m  
 Part number: 140-32-32032-10-10

Please order the needed lengths as follows:

Example for order      Airtherm Ex hose: **7,5 m**  
                                  Airtherm Ex control cable: **5 m**  
                                  Part number: 140-32-32032-**7,5-5**